

Spitfire® XP Pro Series™ Installation Instructions

For your safety and proper product performance

MUST BE SHOT ONLY WITH BLADES IN THE CLOSED POSITION.

MUST NEVER BE SHOT WITHOUT RETENTION CLIPS PROPERLY INSTALLED.

RETENTION CLIPS AND PIVOT SCREWS MUST BE REPLACED AFTER IMPACT HAS OPENED THE BLADES (5) TIMES. MUST NEVER BE SHOT WHEN DAMAGED.

MUST BE CHECKED FOR DEBRIS AND DAMAGE AFTER EVERY SHOT.

BLADES SHOULD BE REPLACED AFTER EVERY HUNTING SHOT - ETHICAL HUNTERS USE ONLY RAZOR SHARP BLADES.

NOTE: BLADES MAY SNAP SHUT AFTER PASSING THROUGH TARGET.

DISASSEMBLY

- 1. With blades closed remove pivot screws with the screw driver provided.
- 2. Carefully remove blades and retention clips.

ASSEMBLY

- 1. Sandwich blade retention clip and blade together (Fig. 1).
- 2. Insert into ferrule slot.NOTE: Sharp edge of blade must face slot in ferrule.
- 3. Align holes in ferrule, blade and retention clip.
- 4. Insert pivot screw in threaded hole and tighten with screw driver.
- 5. Repeat above steps for remaining blades.

