

## **BloodRunner™Installation- The Best of Both Worlds**

Closed Cutting Diameter = 1" Open Cutting Diameter = 1.5"



## **Closed Broadheads**

- 1. Remove the closed broadhead from the tray and insert into wrench (supplied).
- 2. Screw arrow shaft onto broadhead until tight.

## **Open Broadhead**

- 1. Remove open broadhead carefully from package.
- 2. Hold the threaded end and push the point against a hard surface.
- **3.** Using a pair of pliers, remove the yellow tab. Follow the above installation instructions for a closed broadhead.

CAUTION - This product may be extremely dangerous and will cause injury if handled improperly. To avoid injury use the enclosed safety wrench when attaching and removing broadhead.

Store heads in quiver after assembly.